



**BDWS59SS 60 cm Semi-
integrated full height
electronic dishwasher**

INSTRUCTION MANUAL



USER MANUAL FOR YOUR BAUMATIC

BDWS59SS 60 cm Semi-integrated full height electronic dishwasher



NOTE: This User Instruction Manual contains important information, including safety & installation points, which will enable you to get the most out of your appliance. Please keep it in a safe place so that it is easily available for future reference; for you or any person not familiar with the operation of the appliance.

JW 02/04/13

Contents

Environmental note	4
Important safety information	5 – 7
Specifications	8 – 10
Product and aperture dimensions	8
Product specifications	8 – 9
Electrical details	9
Description of the appliance	9
Control panel	10
Using your dishwasher	11 - 23
Before first use	11
Filling with dishwasher salt	11 - 12
Setting the water softener level	12
Filling with rinse aid	13
Setting the rinse aid level	14
Filling with dishwasher detergent	14 - 15
Loading the upper basket	16
Adjusting the upper basket	16
Loading the lower basket	17
The cutlery basket	18
Loading dishes and cutlery	18 - 19
Program table	20
Setting a wash program	21
Changing a wash program	21 - 22
At the end of a wash program	22
Adding an item to the wash	22
Setting a delay start	22 - 23
Rinse aid and salt indicator neons	23
3 in 1 function button	23
Locking the control panel	23
Saving energy using your dishwasher	24
Cleaning and maintenance	25 - 28
The filter system	25
Cleaning the filters	25 - 26
Cleaning the spray arms	26
Cleaning the control panel	26
Cleaning the door	27
Error code failure system	27 – 29
General troubleshooting	28 – 29
Installation	30 - 40
Aperture requirements	30
Preparing and connecting the furniture door	31 - 32
Adjusting the tension of the door spring	33
Connecting to the mains water supply	34
Connecting to the water outlet	35
Connecting to the power supply	35 - 36
Applying the condensation strip	36
Installing the decorative plinth	37
Levelling the appliance	38
Securing the dishwasher	39
Before first use	39
My appliance isn't working	40
Baumatic consumables	41
Technical data	42
Contact details	43

ENVIRONMENTAL NOTE

Note: Before discarding an old appliance, switch off and disconnect it from the power supply. Cut off and render any plug useless. Cut the cable off directly behind the appliance to prevent misuse. This should be undertaken by a competent person. Disable the door lock to make sure that children cannot get stuck inside the appliance.

This appliance is marked according to the European directive 2002/96/EC on Waste electrical and Electronic Equipment (WEEE). By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol  on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



- o The packaging materials that Baumatic uses are environmentally friendly and can be recycled.
- o Please discard all packaging material with due regard for the environment.

IMPORTANT SAFETY INFORMATION



Your safety is of the utmost importance to Baumatic. Please make sure that you read this instruction booklet **before** attempting to install or use the appliance. If you are unsure of any of the information contained in this booklet, please contact the Baumatic Advice Line.

General Safety

- o Repairs to your appliance must only be carried out by a Baumatic engineer or one of its authorised service agents. Any attempt by an inexperienced person to repair the appliance, could result in injury or damage to your dishwasher.
- o If you notice that the mains cable is damaged. **The appliance must not be used.** The same applies if you notice that the worktop, control panel or base area is damaged. As this could allow access to the internal components of the machine.
- o The appliance should be turned off and isolated from the mains supply, before either cleaning or maintenance work is attempted.
- o The mains cable must not be used to pull the plug out of the electrical socket.
- o The machine should not be sprayed with water.
- o The external surface of the appliance may become hot whilst your dishwasher is in use.
- o It is possible for small animals to chew either mains cables or water hoses, which could cause an electric shock hazard.

Installation

- o The installation instructions contained within this user manual should be followed.
- o It is obligatory for the completed installation to comply with all relevant building regulations and local water authority requirements.
- o **Before the first use of the appliance, you should follow the steps listed in the “Before first use” section on page 11 and page 39 of this manual.**

- o Care should be taken not to trap the power supply cable underneath the appliance whilst installing it.
- o No attempt should be made to alter or modify the specifications of this appliance.

In daily use

- o This appliance is only designed to wash normal domestic wash loads. If you use your dishwasher in any other way or it is incorrectly used, then Baumatic accepts no liability for any damage that might be caused and any guarantee will be void.
- o It is recommended that the appliance is unplugged and the water supply is turned off after the machine is used.
- o The detergents, rinse aid and salt that you place in this appliance should be suitable for automatic dishwashers. With regards to dosage levels, the detergent manufacturer's recommendations should be followed.
- o Sharp knives or ones with long blades are a potential safety hazard when placed in an upright position in the cutlery basket. We would recommend that these items are placed horizontally in the upper basket.
- o **You should not** wash any items that have come into contact with corrosive, acidic or alkaline chemicals, paint, petrol, iron or steel debris.
- o **You should not** open the door whilst the appliance is set on a wash program. Depending on which stage that the wash program is at, hot water could escape the machine.
- o **You should not** leave the door of the appliance open, unless you are loading or unloading the dishwasher.
- o **You should not** stand or sit on the door when it is open.

Child Safety

- o Your dishwasher should only be used by adults. You should not allow children in the area of the machine unsupervised. You should not let them touch the controls or play with the appliance.
- o It could be possible for a child or pet to gain access to the dishwasher if the door is left open. Therefore please check the inside of the appliance before setting it on a wash cycle.
- o Any packaging that is removed from the machine should be kept away from children.
- o All detergents should be kept out of children's reach in a safe place.
- o Some water will remain inside the dishwasher when it has completed a wash cycle. This water is not suitable for drinking and may contain residues from the detergents that are used in the appliance.

Declaration of conformity

This appliance complies with the following European Directives:

-73/23 dated 19/02/1973 Low Voltage Directive and subsequent modifications.

-89/336 dated 03/05/1989 Electromagnetic Compatibility Directive and subsequent modifications.


For future reference please record the following information which can be found on the rating plate and the date of purchase which can be found on your sales invoice. The rating plate of your dishwasher is located on the right hand side of the drop down door.

Model Number

Serial Number

Date of Purchase

Specifications



Product dimensions

Height: 820 - 870 mm
Width: 596 mm
Depth: 575 mm

Aperture dimensions

Height: 825 mm (min)
Width: 600 mm
Depth: 595 mm (min)

Product specifications

- o **12 Place settings**
- o **6 functions:** Normal
Intensive
Economy
1 Hour
Rapid
Rinse
- o **4 temperatures:** 40°C, 45°C, 46°C, 60°C,

- o Delay timer
- o LED display
- o Self-cleaning stainless steel micro-filter
- o Anti-leak device
- o Anti-flood device
- o Height adjustable upper basket
- o Collapsible plate racks
- o Adjustable feet
- o Residual drying
- o Concealed heating element
- o 3 in 1 option
- o Quiet operation (49 dB)

Energy efficiency details

Energy efficiency class: A+

Washing performance class: A

Drying performance class: A

Power consumption


Off mode: 0.35 W

Left on mode: 0.90 W

Electrical details


Rated voltage: 220 - 240 Vac 50 Hz

Supply connection: 13 A (double pole switched fused outlet with 3 mm contact gap)




Description of the appliance

Control panel



- 1) ON/OFF button
- 2) Program selection button
- 3) 3 in 1 function button
- 4) Delay start button
- 5) Start / Pause button
- 6) LED display

- 7) Rinse aid indicator neon
- 8) Salt indicator neon
- 9) 3 in 1 indicator
- 10) Washing indicator light
- 11) Child lock indicator
- 12) Drying indicator light



Using your dishwasher

Before first use

- o Install the appliance as per the installation instructions contained within this booklet.
- o Add water to the water softener compartment and then add approximately 2Kg specialist dishwasher salt to the dishwasher. After this you should set the water softener level.
- o Fill the rinse aid dispenser and then set the rinse aid dosage.

Filling with dishwasher salt



IMPORTANT: You should only use salt that is specially designed for use in a dishwasher. If any other type of salt is used in the appliance (in particular table salt), it will damage the water softener.

- o Ideally you should fill the water softener with salt, just before you are about to run a wash program. This will help to clear any salt that may have overflowed from the water softener during the salt filling process.
- o Open the door of the dishwasher and then remove the lower basket. The basket should be empty when you remove it.



- o Turn the water softener cap anticlockwise and remove it.
- o Pour 500ml of water into the water softener.

IMPORTANT: It is only necessary to do this when you fill the container with salt for the first time.



- o Pour salt into the water softener, using the funnel that is supplied with the appliance. You should add approximately 2 kg of salt into the water softener.
- o It is perfectly normal for a small amount of water to come out of the water softener, whilst you are filling it with salt. This does not mean that the water softener is filled with the correct amount of salt.

- o Refit and fully tighten the water softener cap.
- o The salt required warning light will go out approximately 2-6 hours after you have filled the water softener with salt. When the salt indicator neon lights on the control panel, then you should follow the filling with dishwasher salt procedure again.
- o **IMPORTANT: You do not need to pour 500ml of water into the container when you subsequently fill the water softener with salt.**


Setting the water softener level

It is possible to regulate the amount of salt that the water softener will release during a wash cycle. The water softener should be set to a level that is appropriate for the hardness of your water (please refer to the table below).

WATER HARDNESS				Selector	Salt consumption (gram / cycle)	Usage (cycles / 1 kg)
° dH	° fH	° Clarke	Mmol / L			
0-10	0-17	0-12.5	0-1.7	/	0	/
10-25	17-44	12.5-31.3	1.7-4.4	-	20	60
25-50	44-89	31.3-62.5	4.4-8.9	Mid	40	40
>50	>89	>62.5	>8.9	+	60	25

To alter the amount of salt that is released by the water softener, you should:-

- o Remove the lower basket and unscrew the cap from the water softener.



- o Locate the ring with an arrow on it that is located on the water softener. (See figure opposite).
- o When you first receive your appliance, the arrow will be pointing to the minus symbol. Using the water hardness chart, you should turn the arrow to the setting that is appropriate for your water hardness.
- o The “middle” selector position is halfway between the minus and plus symbols.
- o **IMPORTANT: If you are using 3 in 1 dishwasher tablets and live in a medium or hard water area, then you should still fill the water softener with salt. The water softener arrow should be turned to the minus setting.**

Filling with rinse aid



The rinse aid is released during the final rinse and it helps to prevent water from forming droplets on your dishes. These droplets will lead to spots and streaks being left on items after the wash program has completed.

- o Your dishwasher is designed to utilise liquid rinse aid.
- o The rinse aid dispenser is located inside the drop down door, next to the detergent dispenser.



- o To access the rinse aid dispenser, you should turn the cap anticlockwise and it will pop out of the hole **(1)**. Then slowly pour in liquid rinse aid **(2)**, the rinse aid dispenser will hold approximately 110 ml of rinse aid.
- o You should continue to fill with rinse aid, until the level indicator turns completely black.
- o Be careful not to overfill the dispenser, as this could cause oversudsing when a wash program is selected. Wipe away any rinse aid excess or spillages with a damp cloth.
- o Replace the cap and turn it clockwise until it locks into position **(3)**.
- o You should refill the rinse aid dispenser when the rinse aid indicator neon lights on the control panel.
- o **IMPORTANT:** *If you are using 3 in 1 dishwasher tablets then you should still fill the rinse aid dispenser.*

Setting the rinse aid level

The amount of rinse aid that the dishwasher requires also depends on the hardness of your water. You should experiment with the rinse aid setting, until you find a level that gives the best results.






- o On the first wash cycle, we would recommend that the rinse aid level is set to number 4.
- o If you get water spots and poor drying performance, then you should turn the arrow anticlockwise and increase the setting to the next number.
- o You should continue to adjust the rinse aid level upwards until you get no water spots.
- o If you get cloudiness or streaking on your dishes, the rinse aid level is set too high and it is causing foaming during the wash cycle. Turn the arrow clockwise and lower the setting to the next number.

Filling with dishwasher detergent

The detergent dispenser must be refilled at the start of each wash cycle (apart from the Rinse wash program).

- o Open the lid that closes over the detergent dispenser and place the detergent inside of the dispenser.





- o The section marked 1 in the diagram is for the main wash cycle detergent. Only one detergent tablet should be placed in the dispenser at any one time. If you are using detergent powder or liquid, you should follow the detergent manufacturer's recommendations.

- o The section marked 2 in the diagram can have separate detergent placed in it for any wash cycle that has a pre-wash element to it, however this is optional. This must be a liquid or powder detergent, not another detergent tablet.
- o Shut the detergent dispenser lid and position the clip on the outer edge, so that it holds the lid shut.
- o At the beginning of a wash cycle the clip will open and the tablet/powder/liquid will enter the dishwasher.

Concentrated detergent


- o The use of the NORMAL program with concentrated detergents reduces pollution and is good for your dishes.
- o This wash program is specifically suited to the dirt-dissolving properties of the enzymes of concentrated detergent. For this reason, the NORMAL program, in which concentrated detergent is used, can achieve the same results achieved in the INTENSIVE program.

Detergent tablets

- o Different brands of detergent tablets dissolve at different speeds. For this reason, some detergent tablets cannot dissolve and develop their full cleaning power during short programs.
- o It is recommended that you use longer programs when using detergent tablets to ensure the complete removal of detergent residues.

Loading the upper basket

The upper basket is most suited to washing delicate and light dishware, such as glasses, coffee & tea cups, saucers, plates, bowls and shallow pans (that are not heavily soiled).



- A. Cups
- B. Glasses
- C. Saucers
- D. Small serving bowl
- E. Medium serving bowl
- F. Large serving bowl
- G. Serving spoon

- o You should position the dishes and cookware in such a way that they are not moved by the spray of water during the wash cycle.
- o Use the diagram opposite as a guide to the most appropriate way to load the upper basket.

Adjusting the upper basket


Your dishwasher has an adjustable upper basket which you can alter to the most suitable position for the items you are going to wash in the upper and lower baskets.



- o The height of the upper basket can be adjusted by placing the wheels on a different height of the rails. Long items such as cutlery, salad servers and knives should be placed on the shelf so they do not obstruct the rotation of the spray arms.
- o **IMPORTANT:** The upper basket must be empty when you are removing it from the guide supports.
- o NOTE: For easier stacking of pots and pans the cup shelf spikes can be folded down.

Loading the lower basket


The lower basket is most suited to washing larger and more heavily soiled items, such as saucepans, saucepan lids and serving dishes. You can also load bowls and a variety of plates into the lower basket.




- H. Dinner plates
- I. Side plates
- J. Serving plate
- K. Dessert dishes

- o Saucepans and serving bowls must always be placed with their bases upwards.
- o Deep saucepans should be slanted, to allow water to run off.

Folding spikes of lower basket




- o The bottom rack has prongs that can be folded downwards, to allow for easier loading of larger saucepans and serving bowls.



The cutlery basket

Cutlery should be placed inside of the cutlery basket. The cutlery basket should then be placed in the appropriate position in the lower basket.



1. Teaspoons
2. Dessert spoons
3. Soup spoons
4. Forks
5. Knives
6. Serving fork
8. Gravy ladle

- o For the best washing performance, cutlery should be placed through the slots in the top of the cutlery basket.

IMPORTANT: Do not allow items of cutlery to fall through the bottom of the cutlery basket, as this may cause damage to the spray arm and/or the cutlery. If the bottom of the basket begins to deteriorate and allows items to fall through, you should replace the cutlery basket.

Loading dishes and cutlery



Household cloths, sponges or any other object that may absorb water *SHOULD NOT* be washed in a dishwasher.

- o Remove leftovers and soften the remnants of burnt food in pans, prior to loading dishes in the appliance.
- o Once the dishwasher has been loaded, check that the spray arms can move freely. If the spray arm comes into contact with any item, then you should rearrange the wash load.
- o Cups, glasses, pans etc should all be loaded with their bases upwards, so that water does not collect inside of them.
- o Cutlery and dishes should not cover each other; otherwise you may get poor wash results.
- o Do not allow glasses to touch inside the dishwasher, otherwise damage may occur.



The following items are NOT suitable for washing inside a dishwasher:-

- o Cutlery with a handle of mother-of-pearl, wood, horn or china.
- o Plastic items that are not resistant to heat.
- o Cutlery that consists of glued parts that are not resistant to heat.
- o Cutlery items or crockery that are bonded.
- o Copper or pewter items.
- o Lead crystal glass.
- o Wooden platters.
- o Synthetic fibre items.



The following items are not always suitable for washing inside a dishwasher:-

- o Stoneware should only be washed if the manufacturer of the item has marked it as dishwasher safe.
- o Plastic items (such as lunchboxes) should only be washed if the manufacturer has marked it as dishwasher safe.
- o Glazed crockery may fade with repeated washing inside of a dishwasher.
- o Items made of silverware or aluminium can discolour when washed inside a dishwasher.
- o Any food residue should be removed from silver items immediately, as this can also result in discolouration.
- o Certain types of glass may become dull or cloudy after a large number of washes.

Program table

- o The NORMAL program is suitable for cleaning a typical load of dirty dishes and is the most efficient in terms of its combined energy and water consumption.

Program	Program information	Description of cycle	Detergent pre / main	Wash Times*	Water (l)	Energy (kWh)
Normal ** 	For normally soiled loads, such as pots, plates, glasses and lightly soiled pans, standard daily cycle.	Pre-rinse Wash (46°C) Hot rinse Drying	5 grams (pre-rinse) 25 grams (main wash) (Or 3 in 1)	172 Minutes	13	1.03
Intensive 	For the heaviest soiled loads, such as pots, pans, casserole dishes and dishes that have been sitting with dried food on them for awhile.	Pre-rinse Wash (60°C) Rinse 1 Rinse 2 Hot rinse Drying	5 grams (pre-rinse) 25 grams (main wash) (Or 3 in 1)	180 minutes	17	1.30
Economy 	For lightly soiled loads, such as plates, glasses, bowls and lightly soiled plates.	Pre-rinse Wash (45°C) Hot rinse Drying	5 grams (pre-rinse) 20 grams (main wash) (Or 3 in 1)	137 Minutes	14	0.85
1 Hour 	For dishes that need to be rinsed and dried only.	Hot rinse 1 Hot rinse 2 Wash (60°C) Drying	5 grams (pre-rinse) 20 grams (main wash)	60 minutes	10	0.95
Pre-rinse 	To rinse dishes that you plan to wash later that day.	Rinse		11 Minutes	0.01	4
Rapid 	A shorter wash for lightly soiled loads that do not need drying.	Wash (40°C) Hot rinse	15 grams (main wash)	39 Minutes	0.50	7

* The wash program times that are quoted are intended as a guide only. Please note that factors external to the machine, e.g. the temperature of your water supply, your water pressure etc., can affect the time it takes for the wash program to complete.

** Normal is the testing program for EN 50242.

Setting a wash program



Make sure that the “before first use” section has been followed.

- o Check whether the appliance needs rinse aid or salt adding to it.
- o Pull out the top and bottom baskets, then load them in accordance with the loading instructions.
- o Push the top and bottom baskets fully back into position.
- o Add detergent
- o Turn the appliance on by using the ON/OFF button.

IMPORTANT: Wait for 5 seconds before pressing the program selection button, otherwise the appliance may not function correctly.

- o Press the program selection button to choose an appropriate wash program for the load that you are washing. The relevant program indicator neon will light to show which program you have selected.
- o Select any program options that you want to use (e.g. delay start).
- o Close the door firmly, so that you hear the door lock click shut.
- o After a few seconds, you will hear the appliance begin to fill with water and the wash program will have started.

Changing the wash program

IMPORTANT: This should only be attempted when the cycle has only just started, otherwise the detergent tablet may have already released or you could have hot water escaping.

- o Slightly open the door of the appliance.
- o Wait for a minute before fully opening the door to ensure the spray arms have stopped working, and to avoid scalding.
- o Press and hold down the program selection button for 3 seconds to cancel the wash program. Then use the program selection button to choose the correct wash program.
- o Select any program options that you want to use (e.g. delay start).
- o Close the door firmly, so that you hear the door lock click shut.

- o After a few seconds, you will hear the appliance begin to fill with water and the wash program will have started.

At the end of a wash program

- o A buzzer will sound six times.
- o Use the ON/OFF button to switch the dishwasher off.
- o We would advise waiting for at least a few minutes before unloading the dishwasher to avoid handling items which will still be very hot and more susceptible to breakage. Items will also dry better if they are left for longer in the dishwasher before unloading.
- o Open the door of the appliance and unload the dishwasher.

Adding an item to the wash

NOTE: If you open the door during a wash cycle the machine will pause. When you close the door the machine will continue working after 10 seconds.

- o Slightly open the appliance door and wait for the spray arms to stop working. This will avoid scalding by hot water.
- o Fully open the door and add your required item to the basket.
- o Close the door. The appliance will resume the wash after 10 seconds.

Setting a delay start

It is possible to delay the start of the wash program for up to a maximum of 24 hours. The delay can be set in 1 hour intervals.

- o Check whether the appliance needs rinse aid or salt adding to it.
- o Pull out the top and bottom baskets, then load them in accordance with the loading instructions.
- o Push the top and bottom baskets fully back into position.
- o Add detergent
- o Close the door firmly, so that you hear the door lock click shut.
- o Turn the appliance on by using the ON/OFF button.

IMPORTANT: Wait for 5 seconds before pressing the program selection button, otherwise the appliance may not function correctly.

- o Press the program selection button to choose an appropriate wash program for the load that you are washing. The relevant program indicator neon will light to show which program you have selected.
- o Then press the delay start button and you will see the amount of time that you are delaying the wash program by appear in the LED display (1, 2, 3,...23, 24 hours).
- o Once the period of time that you set has passed, the dishwasher will start the wash program that you selected.

Rinse aid and salt indicator neons

- o The rinse aid and salt indicator neons on the control panel will let you know when the appliance needs rinse aid or salt adding to it.
- o The  neon indicates that you need to add rinse aid to the appliance. You should follow the procedure outlined on page 13.
- o The  neon indicates that you need to add dishwasher salt to the appliance. You should follow the procedure outlined on page 11.

3 in 1 function button

- o Press this button when you are using a 3 in 1 dishwasher tablet. This will optimise the wash program you are using for use with a 3 in 1 detergent tablet.

Locking the control panel

- o You can lock the control panel to prevent accidental misuse. No buttons will be operational when the control panel is locked.
- o Press the 3 in 1 button and the delay start button simultaneously for 3 seconds to activate or deactivate the child lock.

Loading dishes

- o Refer to the relevant section of this manual for instructions on placing items in the dishwasher for the most efficient cleaning.
- o Only run the dishwasher when it is full for optimum energy and water usage.
- o Check the program table to select the most efficient program according to the size and type of the load.
- o The ECONOMY program washes your items at a lower temperature and uses less electricity during the cycle. That is better for the environment and helps to cut energy costs.

Usage

- o Clean the filters regularly both to keep the dishwasher clean and to maintain its efficiency.
- o Always remember to switch the appliance off standby when you have finished using it. £1 billion worth of energy is wasted in the UK every year by people leaving appliances on standby.
- o You do not need to rinse dishes off before loading. If you prefer to pre-rinse, use cold water on your dishes before loading them but do not waste water by letting it run continuously.
- o Use the shorter and lower temperature cycles for everything but the dirtiest dishes. Shorter cycles use less energy and work just as well. Modern detergents also work just as well at lower temperatures.


Cleaning and maintenance



IMPORTANT: *The appliance should be disconnected from your mains supply before commencing any cleaning process.*

The filter system

Your appliance is fitted with three levels of filtering; these are located in the base of the dishwasher for ease of access.



- 1) Main filter
- 2) Coarse filter
- 3) Fine filter

Main filter-

Food and soil particles are trapped by this filter and pulverised by a special jet on the lower spray arm. This debris is then washed down the drain.

Coarse filter-

Larger items such as pieces of bone or glass, which could clog the drain, are trapped in this filter.

Fine filter-

This filter holds soil and food residue in the sump area and prevents it from being redeposited on the dishes during a wash cycle.



IMPORTANT: *Whilst the filtering system is efficient, your dishwasher is not a waste disposal unit. All items being washed inside of the dishwasher should have food scraps removed from them before being loaded into the appliance.*

Cleaning the filters

For best performance and results, the entire filter assembly should be thoroughly cleaned regularly (ideally after each wash cycle).



1. Turn the coarse filter anti-clockwise and then lift it upwards. The fine filter will come out with the coarse filter. Rinse out these sections under a tap to remove any food debris that remains in it.



2. Pull out the main filter and rinse this under the tap to remove any food debris that is trapped in it.
3. Place all filters back in their original position.
4. You must turn the coarse filter clockwise to lock it back into position.


IMPORTANT: *If a glass gets smashed inside of the appliance, you must check there is no glass in the filter before the machine is used again as this can cause a drainage failure.*



IMPORTANT: *THE DISHWASHER SHOULD NEVER BE SET ON A WASH CYCLE WITHOUT THE FILTERS BEING INSIDE OF THE APPLIANCE.*

Cleaning the spray arms

The spray arms should be cleaned regularly, to prevent hard water deposits from clogging the spray arm jets and bearings.




- o To remove the spray arm, unscrew the nut and take out the washer that sits on top of the spray arm.
- o Gently pull upwards to remove the spray arm.
- o Wash the spray arm in warm, soapy water and use a soft brush to clean the jets.
- o Rinse the spray arm thoroughly and then reassemble the spray arm back in its original position.

Cleaning the control panel

IMPORTANT: *Do not use any abrasive cleaner or household polish on either the control panel or operating parts.*

- o Wipe over the control panel using a brand new damp cloth with warm water.

Cleaning the door



- o To clean the edge around the outside of the door, you should use a soft, damp cloth only.
- o To prevent water from penetrating the door lock or electrical components, **DO NOT** use a spray cleaner of any kind.
- o **DO NOT** use any abrasive cleaner or scouring pads on the inner or outer surfaces, as they may cause damage to them.

Error code failure system

The following error codes can possibly be remedied by the customer and the maintenance steps outlined below should be followed.

BEFORE COMPLETING ANY MAINTAINANCE ON THE APPLIANCE, IT SHOULD BE DISCONNECTED FROM YOUR MAINS POWER SUPPLY.

E-2

- o Longer than expected fill time.
 - ✓ Check the water pressure of your mains water supply.
 - ✓ Clean the mesh filter that sits in the inlet hose.
 - ✓ Ensure that the inlet hose is not kinked or crushed.
 - ✓ Make sure the water tap that the machine is connected to is turned on fully.

E-3

- o Longer or extended drain time.
 - ✓ The drain pipe may be placed in too high a position or incorrectly. Check the installation instructions and ensure that the installation is correct.
 - ✓ Check that the outlet hose is not kinked or crushed.
 - ✓ Make sure that the drain hose has not been extended beyond its original length.

E-3

The machine has sensed water in the base.

- ✓ Check that the outlet hose is not kinked or crushed.
- ✓ Check that there are no blockages in the drain hose or the drainage system that the appliance is connected to.
- ✓ The drain pipe may be placed in too high a position or incorrectly. Check the installation instructions and ensure that the installation is correct.

CODE	MEANING	POSSIBLE CAUSES
E4	Temperature sensor	Temperature sensor malfunction
E5	Overflow / leakage	Overflow / water leakage occurs
E6	Water leakage	Water leakage occurs
E7	Heating element	Abnormal heating



IF THE FAULT CODE REAPPEARS AFTER FOLLOWING THE ABOVE ADVICE AND CLEARING THE FAULT CODE. YOU SHOULD TURN OFF THE APPLIANCE; DISCONNECT THE APPLIANCE FROM YOUR MAINS SUPPLY. THEN ARRANGE FOR AN ENGINEER TO ATTEND THE APPLIANCE. YOU SHOULD CONTACT THE CUSTOMER CARE DEPARTMENT ON TELEPHONE NUMBER (0118) 933 6911.



IF AN ENGINEER ATTENDS DURING THE GUARANTEE PERIOD AND FINDS THAT A FAULT HAS BEEN CAUSED BY AN ITEM ON THE ERROR CODE LIST, WHICH COULD HAVE BEEN CLEARED BY THE CUSTOMER. THEN YOU MAY BE LIABLE FOR THE COST OF THE SERVICE CALL.

General troubleshooting


PROBLEM	POSSIBLE CAUSES	WHAT TO DO
<i>Dishwasher doesn't run</i>	Fuse blown or the circuit breaker has tripped Power supply is not switched on Water pressure is low	Replace the fuse or reset the circuit breaker. Remove any other appliances that are sharing the same circuit with the dishwasher. Make sure that the dishwasher is turned on and that the door is closed securely. Make sure that the power cord is fully plugged into the wall socket. Check that the water supply is connected properly and that the water is turned on.
<i>Drain pump doesn't stop</i>	Overflow	The system is designed to detect an overflow. If it does, then it will run the drain pump continuously when there is power to the appliance.
<i>Noise</i>	Some audible sounds are normal Utensils are not secure in the baskets or something small has dropped into the basket	You will get a level of operating noise during a wash cycle, in particular when food is being removed from items and when the detergent dispenser places the tablet into the tub. Ensure that everything is loaded as per Baumatic's loading instructions.

	Motor hums	If the dishwasher is not going to be used for a period of time, then you should make sure that the appliance is set on a wash program once a week. Otherwise the seal around the motor may dry out and cause noise.
<i>Suds in the tub</i>	Improper detergent use Spilled rinse aid	Ensure if you are using 3 in 1 detergent tablets, in conjunction with rinse aid and salt that the levels are set correctly. Always wipe up any excess rinse aid or rinse aid spillages immediately.
<i>Stained tub interior</i>	Detergent with colourant was used	Use a detergent without colourant.
<i>Dishes are not fully dried</i>	Rinse aid dispenser is empty	Make sure that the rinse aid dispenser is filled with rinse aid.
<i>Dishes and pans are not clean</i>	Improper program Improper loading	Select a more intense wash program. Make sure that the spray arms and the detergent dispenser are not being impeded by large dishes.
<i>Spots and filming on glasses and pans</i>	Extremely hard water Low inlet temperature Improper loading Improper detergent Incorrect salt / rinse aid levels	Refer to the relevant sections of this booklet, to ensure that the detergent, salt and rinse aid levels are set correctly. Ensure that the appliance is loaded correctly.
<i>Steam</i>	A normal phenomenon	You may get a small amount of steam coming through the vent by the door latch, during drying and water draining.
<i>Black or grey marks on dishes</i>	Aluminium utensils have rubbed against dishes	Use a mild abrasive cleaner to eliminate the marks. Make sure that the appliance is loaded correctly in future.
<i>Water standing in the bottom of the tub</i>	This is normal	A small amount of clean water in the base of the appliance is not something to be concerned about.
<i>Dishwasher leaks</i>	The rinse aid dispenser is overfilled or rinse aid has been spilt inside the appliance Dishwasher isn't level	Take care not to overfill the rinse aid dispenser. Spilt rinse aid could cause oversudsing and lead to overflowing. Wipe away any spills immediately with a damp cloth. Make sure that the dishwasher is level.


Installation



IMPORTANT: THIS INSTALLATION MUST BE COMPLETED BY A SUITABLY QUALIFIED PERSON. BAUMATIC ONLY SANCTION THE INSTALLATION GIVEN IN THIS INSTRUCTION MANUAL. YOU SHOULD DISPOSE OF ALL PACKAGING IN AN ENVIRONMENTALLY FRIENDLY MANNER.




Aperture requirements



Installation stages

1. Preparing and connecting the furniture door
2. Adjusting the tension of the door spring
3. Connecting to the mains water supply
4. Connecting to the water outlet
5. Connecting to the power supply
6. Applying the condensation strip
7. Positioning the dishwasher
8. Levelling the dishwasher
9. Securing the dishwasher


Preparing and connecting the furniture door




IMPORTANT: The furniture door is not supplied with the appliance. You should purchase one to match with the rest of your kitchen cabinets.

- o **The maximum weight of the furniture door should be 7 kilograms. The maximum thickness of the furniture door should be 15 mm.**
- o Use the installation template supplied with the appliance to mark up and then drill out the necessary holes in the furniture door.

- o Screw the 2 fixing plugs onto the furniture door.




- o Assemble the furniture door onto the dishwasher door, ensuring that the fixing bushes locate into the slots on the dishwasher door.
- o Lift the furniture door upwards so it locks into place on the dishwasher door.



- o Open the dishwasher door and secure the furniture door to the appliance door with the 4x44 screws through the holes each side of the dishwasher
- o Fully tighten the screws into the holes. Make sure that you screw them tightly into the furniture door.

Adjusting the tension of the door spring

- o The door of the dishwasher is attached to springs. These are set at the factory to ensure that they are at the proper tension, so that the door can open and close smoothly.




- o After the furniture door has been fitted, you will need to adjust the tension of the door spring.
- o Fully open the appliance door to allow access to the adjusting screws.
- o Using a spanner or similar tool, rotate the adjusting screws which are located on the front top corners of the appliance, to either tighten or slacken the steel cable.
- o The doors spring tension is correct when:-
 - a)** The door remains horizontal when in the fully opened position.
 - b)** You are able to shut the door easily, by raising the door using your fingers.
- o ***WARNING:*** If you do not adjust the tension of the door spring, then it could cause damage to the appliance.

Connecting to the mains water supply




IMPORTANT: Do not connect the appliance to your mains water supply using an old or an existing water inlet hose. The inlet hose supplied with the dishwasher is the **ONLY** one that should be used.

DO NOT CONNECT THE WATER INLET HOSE TO A HOT WATER TAP.




- o The inlet hose will be located inside the cabinet of the dishwasher.
- o Connect the water inlet hose **(C)** to a threaded water tap **(A)** that has a 3/4" thread and to the inlet hose connector on the appliance.
- o Fully tighten the inlet hose to the water tap and the dishwasher.

Connecting to the water outlet




- o Secure the drain hose, so that it cannot move whilst the dishwasher is in use.
- o Place the end of the drain hose on your drain pipe. Push it a short way down into your drain pipe.
- o **IMPORTANT:** Do not insert the drain hose too deeply into the pipe, as this may cause siphoning.
- o **NEVER EXTEND THE DRAINAGE HOSE FROM ITS ORIGINAL LENGTH.**

Connecting to the power supply




- o **IMPORTANT:** The electrical socket must still be accessible once the appliance is installed.



- o Consult the rating plate, located on the right hand side of the drop down door **BEFORE** making the electrical connections. Ensure that the voltage reaching the plug is the same as that on the rating plate.

- o **DO NOT REMOVE THE RATING PLATE AS THE INFORMATION ON IT IS IMPORTANT.**
- o The moulded plug that is supplied with the appliance must be placed into an earthed and insulated socket.
- o Broken or damaged power leads must only be replaced by a suitably qualified person. A power lead of a similar type must be used in replacement.
- o Power lead type – H 0 V V – F 3G 1,5.
- o **IMPORTANT:** *We do not recommend that this appliance is connected to an extension lead.*


Applying the condensation strip



- o The condensation strip must be fitted to the underside of the worktop to protect it against the ingress of moisture. The strip will deflect steam that rises from your appliance, away from the underneath of the worktop.

- o The condensation strip will be located inside of your dishwasher.
- o Ensure that the underneath of the worktop is clean before sticking the strip to it.
- o Separate the backing paper away from the strip.
- o Stick the condensation strip to the underneath of the worktop.
- o **IMPORTANT:** *Failure to attach the condensation strip could result in damage to your worktop.*

Installing the decorative door /skirting board (Ornamental plates)



Referenced dimension		
serial number	Ornamental plate	Plate to ornament the skirting board
1	593mm	90mm
2	583mm	100mm
3	575mm	110mm
4	565mm	120mm
5	553mm	130mm
6	544mm	140mm

Notice:


The required height of the skirting board is as per the principle of aesthetic and opening closing the door smoothly, Please check the suggested chart for the reference.

Levelling the appliance


- o **IMPORTANT:** Your dishwasher must be level for it to operate properly.



- o Make sure that the dishwasher is supported whilst it is being levelled, otherwise it may tip over.




- o The rear feet can be adjusted by using the adjusting screw at the front of the appliance.
- o The front feet can be adjusted using a spanner.



- o Use a spirit level to check that the appliance is level.
- o Check that the appliance is level from side to side.
- o Check that the appliance is level from front to back.

Securing the dishwasher

The dishwasher must be secured to the worktop.



- o **Standard worktop:** Secure the dishwasher to the underside of the worktop and both sides of the appliance by using wood screws provided.
- o You should screw through the holes in the pre-drilled brackets in the top and sides of the dishwasher.
- o *NOTE: you may need to remove the screw covers to reveal the screw holes.* Once the screws are secured, the rubber covers can be re-used to cover the screws.
- o The screws should be fully tightened.
- o **Marble/granite worktop:** The material of the worktop will mean that it is impossible to put a screw through the underneath of the worktop.
- o Simply secure the dishwasher to the cupboard on either side, by screwing a wood screw through the pre-drilled holes into the cupboards, as outlined in the standard worktop instructions above.

Before first use

You should check the following before using the appliance for the first time:-

- o That the dishwasher is level and fixed in position.
- o That the water tap is fully open.
- o That there are no leaks at either end of the drain or inlet hoses.
- o That the inlet and outlet hose are fully tightened.
- o That the inlet and outlet hoses are not kinked.
- o That the power is switched on.
- o That the water softener has been filled with 1 500ml of water and salt.
- o That the rinse aid dispenser has been filled.

My appliance isn't working correctly



IMPORTANT: If your appliance appears not to be operating correctly, then you should disconnect it from your mains supply and then contact the Customer Care Department on telephone number (0118) 933 6911.

DO NOT ATTEMPT TO REPAIR THE APPLIANCE YOURSELF.

Please note that if an engineer is asked to attend whilst the product is under guarantee and finds that the problem is not the result of an appliance fault, then you may be liable for the cost of the call out charge.

The appliance must be accessible for the engineer to perform any necessary repair. If your appliance is installed in such a way that an engineer is concerned that damage will be caused to the appliance or your kitchen, then they will not complete a repair.

This includes situations where appliances have been tiled in, sealed in with sealant, have wooden obstructions placed in front of the appliance, like plinths. Or any installation other than the one specified by Baumatic Ltd. has been completed.

Please refer to the conditions of guarantee that appear on the warranty card that you receive with the appliance.

IMPORTANT: Baumatic Ltd. operates a policy of continuous improvement and reserves the right to adjust and modify its products without prior notification.

Baumatic Consumables

- o **BC001** Degreaser for Dishwashers (200 g)
- o **BC002** Descaler for Washing Machines and Dishwashers (200 g)
- o **BC003** Ceramic Hob Cleaner (250 ml)
- o **BC004** Oven Cleaner (250 ml)
- o **BC005** Stainless Steel Cleaner and Protector (250 ml)
- o **BC007** E-Cloth – General Purpose Cloth
- o **BC008** Microwave Cover

To order a Baumatic consumable product please call 0123 5437 244 and quote the product code. You can also order online from eshop.baumatic.co.uk

Technical Data

Manufacturer	BAUMATIC LTD
Model Number	BDWS59SS
Standard Place Settings	12
Energy Efficiency Class (1)	A+
Annual Energy Consumption (2)	289 kWh
Energy Consumption of the Standard Cleaning Cycle	0.92 kWh
Power Consumption of Off Mode	0.34 W
Power Consumption of Left-On Mode	0.90 W
Annual Water Consumption (3)	3640 litres
Drying Efficiency Class (4)	A
Standard Cleaning Cycle (5)	Normal 45°C
Program Duration of the Standard Cleaning Cycle	172 mins
Noise Level	49 dB
Installation Type	Built-in

(1) On a scale from A+++ (highest efficiency) to D (lowest efficiency).

(2) Annual energy consumption based on 280 standard cleaning cycles using cold water fill and the consumption of the low power modes. The actual energy consumption will depend on how the appliance is used.

(3) Annual water consumption based on 280 standard cleaning cycles. The actual water consumption will depend on how the appliance is used.

(4) On a scale from A (highest efficiency) to G (lowest efficiency).

(5) This program is suitable for cleaning normally soiled tableware and is the most efficient program in terms of combined energy and water consumption.

**United Kingdom**

Baumatic Ltd.,
Baumatic Buildings,
6 Bennet Road,
Reading, Berkshire
RG2 0QX
United Kingdom

Sales Telephone

(0118) 933 6900

Sales Fax

(0118) 931 0035

Customer Care Telephone

(0118) 933 6911

Customer Care Fax

(0118) 986 9124

Spares Telephone

(01235) 437244

Advice Line Telephone

(0118) 933 6933

E-mail:

sales@baumatic.co.uk
customercare@baumatic.co.uk
spares@baumatic.co.uk
technical@baumatic.co.uk

Website:

www.baumatic.co.uk

Facebook:

www.facebook.com/baumatic.uk

Republic of Ireland**Service Telephone**

1-890 812 724

Spares Telephone

091 756 771

Czech Republic

Baumatic CR spol s.r.o.
Lípová 665
460 01 Liberec 4
Czech Republic

+420 483 577 200

www.baumatic.cz

Slovakia

Baumatic Slovakia, s.r.o.
Panenská 34
811 03 Bratislava - Staré Mesto
Slovakia

+421 255 640 618

www.baumatic.sk

Germany

Baumatic Gmbh
Bachstr.10-12
D-32257 Bünde
Deutschland

+49 (0) 5223 99408 0

www.baumatic.de

Italy

Baumatic Italia S.R.L.
Via Galvani N.3
35011 Campodarsego (PD)

+3904 9920 2297

www.baumatic.it

Holland

Baumatic Benelux B.V.
Dukdalfweg 15d
1332 BH ALMERE
Nederland

+31(0)36 549 1553

www.baumatic.nl

